

**Club Car DS Front Bumper
Installation Instructions**
Black- Part# 7259
Gunmetal- Part# 7270
Stainless- Part# 7272



Parts List

- Front Bumper-1*
- 1/4 x 1 3/4 Bolts-2*
- 1/4 Locknuts-2*
- Mount-1*
- 3/8 x 1 Bolts-2*
- 3/8 Locknuts-2*




*Always wear appropriate
eye protection!*

For Standard Cart or Jake's Spindle Lift:

1. Remove the stock bumper from the cart as shown in Figure 1.
2. Using the stock bumper bolts mount the front bumper mount to the stock bumper location.
3. Using the supplied bolts mount the front bumper to the front bumper mount.
4. Securely tighten all bolts.

For Jake's Long Travel Lift:

1. Mount the Outlaw Bar mount to the pre-drilled sub-frame using the supplied 3/8 x 1 bolts and nuts.
2. Using the supplied 1/4 x 1 3/4 bolts mount the front bumper to the front bumper mount. Securely tighten all bolts



866-405-2537

www.jakesliftkits.com