

STEERING STABILIZER KIT

For 1994.5~1999 E-Z-GO Medalist/TXT Lifted Car

Will not work with chrome axle cover



Caution: Wear the appropriate eye protection!

- 1) Remove the two rear spring plate bolts (Driver's Side)
- 2) Install the stabilizer bracket to the bolts
- 3) Install the stabilizer cylinder end to the bracket
- 4) Install the rod end of the stabilizer to the passenger side tow bar hole on the forward spindle arm
- 5) You will find two 3/8" flat washers in the kit; they will serve as shims for the rod end nut adjustment
- 6) After the rod end is inserted in the tow bar hole, install the two flat washers and the M10 X 1.25 lock nut
- 7) Tighten the nut until it just touches the washers, back off until a gap is acquired and the end turns freely in the hole. **Failure of free movement (swiveling) will bend the cylinder arm and is not covered under warranty!**

Note: some carts may require slight bending of the bracket or rod end for better fitment

