

PROFX

INSTALLATION INSTRUCTIONS

PFX2011 Adjustable LED Light Kit

Fits Yamaha® G29® / Drive



CAUTION: If you choose not to have this product installed by a professional, we highly recommend that you exercise caution, care, and patience when installing this product as it involves cutting holes into your cart's body.

Please read through the instructions carefully. Before starting this project, remove the system's positive and negative connections from the battery or battery pack. This kit is designed for a 12V-48V operation only. Look behind each drill location **BEFORE YOU DRILL**.

Installer is responsible for damage (i.e. drilling into a wiring harness, battery, fuel tank etc.)

Headlight and Taillight Preparation

1. Cut out the included headlight template following the guidelines.

2. Place the template on the driver side front cowl and align it with the cowl mold lines and bottom edge of the cowl. Secure with painter's tape.

Trace the template using a marking device. Using a jig saw or rotary tool, cut

out the inside of the marked area. Test fit the headlight and make any adjustments before removing the tape. Once the light fits, remove tape and sand any rough edges.

