

**Yamaha G2-G21 Front Bumper
Installation Instructions**
Black- Part# 7256
Gunmetal- Part# 7265
Stainless- Part# 7271



Parts List

- Front Bumper-1*
- 1/4 x 1 3/4 Bolts-2*
- 1/4 Locknuts-2*
- 3/8 x 1 Bolts-2*
- 3/8 Locknuts-2*



*Always wear appropriate
eye protection!*

For Stock & Standard Jake's A-Arm Lift

1. Remove the stock bumper from the cart as shown in Figure 1.
2. Unbolt the stock front a-arm bolts shown in Figure 1.
3. Using the stock front a-arm bolts, nuts, & cotter pins bolt the Outlaw Bar mount to the front frame and a-arms.
4. Using the supplied 1/4 x 1 3/4 bolts & locknuts mount the Outlaw Bar to the Outlaw Bar mount.
5. Securely tighten all bolts.



For Jake's Long Travel Lift

1. Mount the Outlaw Bar mount to the existing holes in the long travel sub-frame using the supplied 3/8 bolts and locknuts as shown in Figure 2.
2. Using the supplied 1/4 x 1 3/4 bolts & locknuts mount the Outlaw Bar to the Outlaw Bar mount.
3. Securely tighten all bolts.



866-405-2537

www.jakesliftkits.com