

# Front Utility Box (Aluminum) Club Car DS 1982-2007 CGB CC5 101



Hardware Kit Includes:  
(4) 1 1/2" X 5/16" X 18 Bolts  
(8) Flat Washers  
(4) 5/16" Locknuts  
Keys (located in box)

Tools needed:  
1/2" Ratchet  
5/16" Ratchet  
Phillips Screwdriver



**CAUTION:** Remember to wear appropriate eye protection while performing the tasks in this instruction.

## Installation Instructions

1. Remove bolts that attach canopy struts to front body of cart. Retain hardware. (See Figure 1)
2. Remove factory bumper using 1/2" ratchet and Phillips screwdriver. Retain hardware. (See Figure 2)
3. Mount U-bracket to front of cart using factory hardware. (See Figure 3)
4. Align brackets on cargo box with holes in canopy struts. The brackets on cargo box will need to be between cart body and canopy strut bracket. (See Figure 4)
5. Align holes in bracket on bottom of utility box, with holes in U-bracket. (See Figure 5). Tighten all hardware at this time.

