


# Nerf Bars with Diamond Plate Step NFB CC3 BLK For Club Car Precedent 2004-Present



 **CAUTION:** Remember to wear appropriate eye protection while performing the tasks in this instruction.

## Installation Instructions:

- 1) Lift cart with a jack and support with stands.
- 2) Place nerf bar against the bottom and outside edges of the golf cart frame. Adjust nerf bar from front to back. (See Figure 1)
- 3) Once nerf bar is in place, mark the (4) pre drilled holes on the nerf bar so that they align with the golf cart frame. (See Figure 2 & 3)
- 4) Remove nerf bar and drill marked holes using a 3/16" drill bit. (See Figure 3)
- 5) Place nerf bars so that newly drilled holes in cart frame align with pre drilled holes on nerf bars.
- 6) Secure nerf bars to cart frame using supplied 1/4" X 1" self tapping screws.
- 7) Repeat steps on other side.
- 8) Remove cart from jack stands.

