

Diamond Plated & Stainless Steel Nerf Bars

Club Car DS 1982-2007

NFB CC5 SS, NFB CC5 CHR, NFB CC5 5125, NFB CC5 BLK, & NFB CC5 RED



Tools Needed:

Drill

3/8" drill bit

1/2" socket and ratchet

1/2" wrench

1/4" socket



CAUTION: Remember to wear appropriate eye protection while performing the tasks in this instruction.

Installation Instructions

1. Verify contents of package. (2) Nerf Bars and hardware.
2. Remove black rubber molding from rocker panel by removing the four retaining screws from the backside of the molding. Retain the hardware for reinstallation (Figure 1).
3. Line up the Nerf Bar onto the rocker panel in desired location and mark the 2 holes (Figure 2).

NOTE: MAKE SURE THE HOLES WILL NOT INTERFERE WITH FUEL TANK ON GAS CARTS.

4. Once holes are marked use a 3/8" drill bit to drill the two holes (Figure 3).
5. Using supplied hardware, attach the Nerf Bar to the back side of the rocker panel.
6. Reattach rubber molding with the 1/4" screws.
7. Repeat steps 2 through 6 on opposite side.

