Clear or Tinted Windblocker Club Car DS 2000.5-Present WND CC2 WBT WND CC2 WBC



INSTALLATION INSTRUCTIONS

- 1. Place windblocker against the front of the windshield frame.
- 2. Slide windblocker up as far as possible on frame.
- 3. Use holes on windblocker to mark frame.
- 4. Drill marked holes with 1/4" drill bit.
- 5. Place plastic rivet through windblocker.
- 6. Place rubber washer between windblocker and frame.
- 7. Push plastic rivet into frame and tap gently with mallet or hammer.
- 8. Windblocker is supposed to sit behind existing windshield.
 * Windblocker will not work with winged windshields.

BW 307

Buggies Unlimited 1-888-444-9994 www.buggiesunlimited.com Copyright©1997-2008 Buggies Unlimited. All Rights Reserved.

Clear or Tinted Windblocker Club Car DS 2000.5-Present WND CC2 WBT WND CC2 WBC



INSTALLATION INSTRUCTIONS

- 1. Place windblocker against the front of the windshield frame.
- 2. Slide windblocker up as far as possible on frame.
- 3. Use holes on windblocker to mark frame.
- 4. Drill marked holes with 1/4" drill bit.
- 5. Place plastic rivet through windblocker.
- 6. Place rubber washer between windblocker and frame.
- 7. Push plastic rivet into frame and tap gently with mallet or hammer.
- 8. Windblocker is supposed to sit behind the existing windshield.
 - * Windblocker will not work with winged windshields.