



Wear the appropriate eye protection!

**CHR E22 2001/2021
Shock Shield
Diamond
Plate/Stainless**



Remove the existing shock shield. You will find in most carts two plastic rivets that will need to be pried out. The upper screws will be removed with either a 3/8" wrench or a 7/16". The new stainless steel hardware will be used for attaching the new cover.



Buggies Unlimited
1-888-444-9994
www.buggiesunlimited.com

© Copyright 1997-2008 Buggies Unlimited. All Rights Reserved.