



Wear the appropriate eye protection!

**SCB EZO BSKT
TXT/MEDALIST
CLAYS BASKET**

The hardware kit consists of:

4 5/16" X 3/4" USS Flange Bolts

4 5/16" USS Nyloc Nuts

Remove the front roof strut bolts on one side at a time. Retain the inner spacer for reuse. Bolt the LH and RH basket brackets to the outside of the roof struts. Leave the bolts loose and install basket to inside of bracket. Now tighten everything securely.

If your car does not use a roof you will need to order BSG EZ2 PLATE kit and HDW EZO KC75048 spacers.

