



## The Drive:



**Caution: Wear Appropriate Eye Protection!**

Side C-channels 52" will mount on the front existing top mounting bolts. Use the supplied 2 1/2" bolts, washers, and nuts for mounting. Notice there are four 3/4" plastic spacers in the kit. Place the spacers between the C-channel and top mounting area, then install the bolts (A). Do not tighten at this time. At the rear of the side C-channels install the self tapping screw on each C-channel (C). Then tighten all hardware. The C-channels face out.



(A)



(B)

The C-channel on the rear (42 3/4") center to match the side C-channel and use the self tapping screws for mounting to top. The C-channels will face and to the inner side of top (C).

**Tech Tip: Dry fit everything before making final fitment.**



(C)