## DSA EZ1 CVR CFBR & DSA EZ1 CVR WDGR Dash Cover with Locking Doors Instructions for EZGO Marathon 1986-1994 Models



Remove center dash/cup holders by drilling out plastic rivets which are placed as shown in picture to the right. Hold dash in place and drill 1/8" pilot holes where noted in picture. (Remove front windshield frame, if necessary for proper dash placement.) Space screw holes on top of dash, evenly spaced as needed. Not all screws must be used. Install screws.

## **Dash Door Installation**

Using door and frame as a template, drill 1/8" pilot holes in each corner. Insert screws and tighten with #2 phillips screwdriver.



