

JAKES LIFT KITS

EZ-GO ST/Clays Car Models Factory Lifted w/ Old

Style Steering

PART # 7254

PARTS LIST



FRONT INSTALLATION

1. Lift the cart with a jack and place on jack stands. Remove the wheels and tires.
2. Unbolt the front leaf springs from the axle. Unbolt the front shocks.
3. Using the supplied nuts/bolts **ITEM C** bolt, leaf spring risers **ITEM A**, & stainless steel front shield **ITEM D**, and stock 3 holed spring plates bolt the risers, leaf springs, and spring plates to the front axle. The front shield is pre-drilled and will mount on the bottom of the front using the 2 front riser bolts as shown.
4. Install new shock extensions **ITEM E** to either the top or bottom of the shock.
5. Securely tighten all bolts.



REAR INSTALLATION

1. Lift the rear of the cart and place it on jack stands. Place a jack under the rear axle housing.
2. Replace rear leaf spring shackles with new shackles provided **ITEM B**.
3. Securely tighten all bolts.

