



Wear the appropriate eye protection!

CHR EZ2 2001/2021
Shock Shield
Diamond Plate/
Stainless



Remove the existing shock shield. You will find in most carts two plastic rivets that will need to be pried out. The upper screws will be removed with either a 3/8" wrench or a 7/16". The new stainless steel hardware will be used for attaching the new cover.

