

6" Yamaha G-Max

Front

-Raise front of car and support with jack stand.

-Remove wheels and front bumper.

-Remove steering linkage and factory steering arms.

-Remove bolts from steering gear.

-Remove factory A-Arms.

-Remove shocks.

-Install new upper shock mounts.

-Install new A-Arm carrier with A-Arms attached.

-Install shocks to A-Arms and then to upper shock mounts.

-Reinstall steering gear.

-Install new steering arms to spindles with factory bolts.

-Install wheels and lower car.

-Adjust steering to 0°-1/8" toe in.

-Adjust cambers with ball joints on lower A-Arms.

Rear

-Raise cart & support frame w/jack stands.

-Remove rear body.

-Remove shocks from top mounts.

-Remove sway bar from bottom mount (Rear-end side).

-Confirm that all wiring & cables are free of binding.

-Install ASK "H" bracket to upper shock mounts .

-Install shocks to "H" bracket.

-Drill sway bar mount (Rear-end side) to 1/2".

-Install ASK sway bar bracket to factory sway bar mount.

-Replace fuel line or bend fuel pump bracket on gas models.

-Inner fender wells may need trimmed or tied back for tire clearance.