

# Yamaha 7" Lift Kit Instructions

**\*\*Offset Wheels are recommended for use with this lift.**

## Front

- Raise cart & support frame w/jack stands
- Remove front bumper
- Remove tie-rods from steering arms
- Remove spindles from factory A-arm
- Remove factory A-arms
- Install ASK A-arms Install factory spindles on ASK front end
- Install ASK Steering risers on top of factory steering arms  
( D = Drivers Side P = Passenger Side)
- ~~Install tie-rods to ASK risers & adjust toe-in (Approx. 1/8")~~

## Rear

- Raise cart & support frame w/jack stands
- Remove rear body
- Remove shocks from top mounts
- Remove sway bar from bottom mount (Rear-end side)
- Confirm that all wiring & cables are free of binding
- Install ASK "H" bracket to upper shock mounts
- Install shocks to "H" bracket
- Drill sway bar mount (Rear-end side) to 1/2"
- Install ASK sway bar bracket to factory sway bar mount
- Replace fuel line or bend fuel pump bracket on gas models
- Inner fender wells may need trimmed or tied back for tire clearance