

**Clear or Tinted Windblocker
Yamaha G14/G16/G19
1995-2002**

WND YA3 WBT

WND YA3 WBC

INSTALLATION INSTRUCTIONS

1. Place windblocker against the front of the windshield frame.
2. Slide windblocker up as far as possible on frame.
3. Use holes on windblocker to mark frame.
4. Drill marked holes with 1/4" drill bit.
5. Place plastic rivet through windblocker.
6. Place rubber washer between windblocker and frame.
7. Push plastic rivet into frame and tap gently with mallet or hammer.
8. Windblocker is supposed to sit behind existing windshield.
* Windblocker will not work with winged windshields.

BW 307

Buggies Unlimited
1-888-444-9994
www.buggiesunlimited.com
Copyright©1997-2008 Buggies Unlimited.
All Rights Reserved.



**Clear or Tinted Windblocker
Yamaha G14/G16/G19
1995-2002**

WND YA3 WBT

WND YA3 WBC

INSTALLATION INSTRUCTIONS

1. Place windblocker against the front of the windshield frame.
2. Slide windblocker up as far as possible on frame.
3. Use holes on windblocker to mark frame.
4. Drill marked holes with 1/4" drill bit.
5. Place plastic rivet through windblocker.
6. Place rubber washer between windblocker and frame.
7. Push plastic rivet into frame and tap gently with mallet or hammer.
8. Windblocker is supposed to sit behind the existing windshield.
* Windblocker will not work with winged windshields.

BW 307

Buggies Unlimited
1-888-444-9994
www.buggiesunlimited.com
Copyright©1997-2008 Buggies Unlimited.
All Rights Reserved.

