

HTR UNV 48V 48-Volt Heater

Installation Instructions For Club Car and Yamaha




BUGGIES
UNLIMITED

Mount the heater to the steering column in a location that will not interfere with steering, or catch on moving parts. On both Club Car and Yamaha golf carts, connect the wiring to a hard positive and a hard negative. **DO NOT USE FRAME GROUND!**




48-Volt Club Car

Connect positive to positive post of battery #1 and connect negative to negative post of battery #6.



48-Volt Yamaha

Connect positive to positive post of battery #1 and connect negative to negative post of battery #6.



Buggies Unlimited
1-888-444-9994
www.buggiesunlimited.com