



Note: MS3 and the ITS is located in the Foot Pedal Box. The Reed Switch (fusible link) is located inside the Charging Receptacle. A in-line fuse can be used to replace the Reed Switch. MS2 and MS4 will be pictured in reverse order as it will appear from the front side. Double black lines are white. If your cart has a diode located on the solenoid, remove and discard it. The diode is connected across the two small terminals on the solenoid.