

STC JL EZ9 I EZGO Steering Stop

Installation Instructions for 1995-2000.5 EZGO TXT Models



Please remember to wear appropriate eye protection

- A)** Raise vehicle and support with jack stands.
- B)** Remove driver's side wheel.
- C)** On the backside of the driver's side of the front axle, locate the edge where the spindle U-bracket is welded to the axle beam.
- D)** Place the steering stop against this edge and mark where the mounting hole will need to be drilled.
- E)** Using a 1/4" bit, drill through the front axle beam.
- F)** Bolt the steering stop to the axle using the supplied 1/4" bolt, washer, and lock nut and tighten to 6-9 foot pounds.
- G)** While applying torque to bolt, hold steering stop in the correct position.
- H)** Reinstall wheel, remove jack stands and lower cart.

